


Hochschule Karlsruhe  
Technik und Wirtschaft  
UNIVERSITY OF APPLIED SCIENCES



# Creo Sketcher Practice

## Part 1

Oliver Stumpf  
Armin Steinke





# Sketch-01: Technical Drawing Basic Chain and Dimension




Workflow in CREO	
1	Horizontal reference
2	Vertical reference
3	Sketch origin and startpoint
4	Automatically generated constraint
5	Automatically generated dimension
6	Manually generated dimension

## Sketch-02: Technical Drawing Basic Chain and Dimension




Workflow in CREO	
1	Horizontal reference
2	Vertical reference
3	Sketch origin and startpoint
4	Automatically generated constraint
5	Automatically generated dimension
6	Manually generated dimension


Sketch-03: Technical Drawing  
 Sketch with „close to sth.“ dimensions





Workflow in CREO	
1	Starting in sketch origin
2;3	Draw line chain with excessive dimensions
4;5	Change dimensions to correct values




## Sketch-04: Technical Drawing Rectangle and Trim-function




Workflow in CREO	
1	Rectangle starting in sketch origin
2	2. Rectangle
3	3. Rectangle
4	Trim with trace
5	Modify + generate dimensions




## Sketch-05: Technical Drawing Tilted Rectangle




Workflow in CREO	
1	Rectangle starting in sketch origin
2	Draw line
3	Tilted rectangle
4	Trim with trace (2x)
5	Modify + generate dimensions




## Sketch-06: Technical Drawing Guidelines and Constraints



Workflow in CREO	
1	Draw roughly a parallelogram
2	Draw guidelines
3	Convert into construction lines
4	Add constraints
5	Modify + generate dimensions





## Sketch-07: Technical Drawing Guidelines and Constraints




### Workflow in CREO


- 1 Circle starting in sketch origin
- 2 Draw line chain
- 3 Use appearing constraints
- 4 Convert circle in construction line
- 5 Add constraints until only ONE dimension is left
- 6 Modify dimension




## Sketch-08: Technical Drawing Tangent Line and Construction Circle



Workflow in CREO	
1	Circle starting in sketch origin
2	Draw circles
3	Draw <b>tangent</b> lines
4	Trim with „mouseclick“
5	Create/convert circle in construction line
6	Add constraints
7	Create/modify dimensions




## Sketch-09: Technical Drawing Symmetry in Sketch




### Workflow in CREO

- 1 Circles and tangent Line
- 2 Draw Center-Lines
- 3 Trim with trace
- 4 Select all
- 5 Mirror horizontally
- 6 Select all and Mirror vertically
- 7 Add and modify dimension



Sketch-10: Technical Drawing  
 Reference Profile of an Involute Gear DIN 867  
 Rescale Sketch  
 Constraints instead of Mathematics



Workflow in CREO	
1	Center line for symmetrie
2	Select all
3	Modify dimensions
4	Enter desired value (Lock Scale!!)
5	Place dimensions
6	Add constraints
7	Change into construction line

2

36.66

16.03

1

32.46

3

Modify  
 Modify the values of dimensions, geometry of splines, or text entities.

By far too large sketch

11.89

6.95

36.66

23.16

16.03

32.46

11.89

6.95

Modify Dimensions

sd250 2 4

sd246 891575366

sd251 157278345

Regenerate

Lock Scale

Sensitivity

OK Cancel

Check

5

3.14

40.00

5

6

7

1.00


1.00

Same Length


Same Length

## Sketch-11: Technical Drawing


The perimeter dimensioning is used to determine eg. the center distance for a given circumference



Workflow in CREO	
1	Draw contour
2	Add two construction circles 20 / 40
3	Generate center distance dimension
4	Activate all contour lines (nothing else)
5	Select Perimeter Dimensioning
6	Pick center distance dimension (it turns variable now)
7	Change perimeter value to 180




## Sketch-12: Technical Drawing Sketch with line offset






### Workflow in CREO

- 1 Draw Point in Origin
- 2 Draw path-line
- 3 Add constraints (use also „midpoint“)
- 4 Add Thicken-Feature (Chain+Circular Ends) select „from-to“ line segments
- 5 Convert path-line to construction-line
- 6 Add and modify dimensions



## Sketch-13: Technical Drawing

### Advanced constraints: Orbiform



Workflow in CREO	
1	Start with three Arcs
2	Add fillets
3	Add coincident constraints to the three centerpoints
4	Add two construction circles
5	Add constraints until only TWO dimension left
6	Modify dimensions

